

Congratulations!...



On selecting your new **Carson X-View Extreme Close Focus Monocular**. With reasonable care, your monocular will provide you with years of enjoyment. In order to achieve optimum performance, please read the instructions carefully on the proper use and care of your monocular.

Instructions for care...

Like any fine optical instrument, your X-View monocular should be given sensible care. Do not drop or violently jar your monocular. This may cause the internal optical components of your monocular to become misaligned and reduce the quality of the image. Do not expose the monocular to excessive moisture.

Cleaning...

Cleaning must be done safely and carefully to avoid scratching the lenses and permanently damaging your monocular. Safe cleaning can be accomplished using a Carson LensPen lens cleaning device. If you do not own a Carson LensPen, please follow the procedure below...

Blow away any dust or debris on the lens (or use a soft lens brush). To remove dirt, grease or fingerprints, clean with a soft cotton cloth rubbing in a circular motion. Use of a coarse cloth or unnecessary rubbing may scratch the lens surface and eventually cause permanent damage. For a more thorough cleaning, photographic type lens cleaning fluid may be used. Always apply the fluid to the cleaning cloth, never directly on the lens.

IMPORTANT: Never attempt to clean your monocular internally or try to take it apart.

Focusing your monocular...

When viewing objects at close range focusing is accomplished by turning the large focus wheel closest to the objective lens of the monocular. Turning this focus wheel will extend the objective lens outward. This is a normal part of the focusing system.

When viewing objects at a distance, turn the large focus wheel until the objective lens is at its inward most position. Once this is done, focusing is accomplished by turning the small focus wheel closest to the eyepiece.

Your monocular is fitted with a twisting eyecup which raises and lowers the eyecup. Raising the eyecup will eliminate extraneous light. For eyeglass wearers, lowering the eyecup will bring your eyes closer to the monocular lens, thus providing an improved field of view.

The X-View is equipped with a standard tripod mount and can be attached to most tripods for easy hands-free use.

CAUTION: VIEWING THE SUN CAN CAUSE PERMANENT EYE DAMAGE. DO NOT VIEW THE SUN WITH THIS MONOCULAR OR EVEN WITH THE NAKED EYE.



35 Gilpin Avenue
Hauppauge, New York 11788
Phone: 631-963-5000 Fax: 631-427-6749
email: info@carson-optical.com
www.carson-optical.com